

INSTALLATION INSTRUCTIONS



Step1:Twist adaptor into socket.



Step2: Insert male connector into female one.



Step3: Insert LED trim.