



INSTALLATION INSTRUCTION

IMPORTANT:



Replace any cracked protective shield

Switch off & Isolate from the mains supply before installation and any maintenance

